



### Placing a Call

- Dial an extension number
- Or: Dial the external number required

### Call Transfer

- While connected to an outside line, press the **TRANS/PGM**
- Dial the desired extension number, (**700-899**)
- Hang up to complete call transfer
- Or: Announce the call, then hang up to complete call transfer

### External Call Transfer

- While connected to an outside line, press the **TRANS/PGM**
- Press flex key required
- Hang up to complete call transfer
- Or: press the **TRANS/PGM**
- Press Speed key (soft key)
- Select System Speed Dial
- Press **Send** (soft key)

### Call Pick-up

- Press **Pick Up** to answer an unattended phone ringing in your area
- Dial **\*1** to answer an unattended phone ringing in your area

### Using Speed Dial Numbers

- Press the **Dir** Soft Button
- Press the **Speed** Soft Button
- Dial the speed bin number you wish to call (**01-19** or **200-999**)

### Dialing By Name

- Press the **Dir Soft** Button
- Dial **1** for Private Directory or **2** for Public Directory
- Dial letter you require (using the "Dial By Name Chart") /or toggle up or down with navigation key
- Press **Send**

### Intercom Answer Mode

- Press **Trans/Pgm** button.
- Dial **13**
- Dial **1**, for Hands-free, **2** for Tone ring, or **3** for Privacy announce
- Press **Hold/Save** button

### Ring Type Mode

- Press **Menu** button
- Press **1** Phone Settings
- Press **2** for internal or **3** for external Ring Tone
- Choose dial tone **01 to 08**
- Press **Hold/Save** button

### Do Not Disturb (DND)

- Dial **Dnd/Fwd - 24** button (Toggle On/Off)
- Dial **\*53** (Toggle On/Off) - 8 button

### Redial

- Dial **52** - automatically starts last number redial
- Or press **Log** soft key to show dialed calls

## User Guide

### Paging

- Dial **#00** For "All Call" Paging
- Dial **#7** For "Internal" Paging
- Dial **#5** For External Paging

### Voice Mail

**Dial 999, enter your extension number followed by your pass-word.**

### Default Password:

#### Greetings:

**Record Greeting** Press **8**

#### Messages:

**Retrieve Message** Press **1**

**Delete Message** Press **3#** or **Delete Soft Key**

**Save/Skip Message** Press **2**

**Replay Message** Press **1**

### Call Forward

- Dial **49**
- Dial the desired call forward type
  - 1 - Immediate**
  - 2 - Busy**
  - 3 - No Answer**
  - 4 - Busy/no answer**

- Dial the destination you wish to forward your calls to (**700-899** or dial **999** to send to Voice Mail)

### To cancel a Call Forward

- Dial **59**

### Retrieving Voice Mail Messages Externally (DDI's)

- Dial **DDI Number**
- During Message press # key
- Enter Authorisation Code (2 to 5 digits) followed by #
- Follow prompts

### Recording Telephone Conversations-24 Button KP Only

- When connected to Party, press navigation button to right
- Press **Record** (soft key)
- This will be saved in Voicemail and retrieved as a message



### Holding Calls

- To place call on hold
- Press the **HOLD/SAVE** button
- To retrieve
- Press flashing line flex button

### Call Park

- While connected to an outside call
- Press the **TRANS/PGM**
- Dial the Call Park Location (**601-609**)
- Hang up

### Retrieve a Parked Call

- Dial the Call Park Location (**601-609**)

### Flexible Keys

#### Program Flexible Buttons

- Press the **TRANS/PGM** button
- Press a flexible button you wish to program
- Enter the desired code (*refer to the table below*)
- Press the **HOLD/SAVE** button



Extensions	700-899
Call Park	601-609
Group Call Pickup	*1
Speed Dial	Speed 01-19 Speed 200-999
Call Log	TRANS/PGM + 57
Background Music	TRANS/PGM + 73
Call Back	TRANS/PGM + 92
Redial	TRANS/PGM + 97
Conference	TRANS/PGM + 91
Flash	TRANS/PGM + 94
Speed	TRANS/PGM + 90
Call Record	TRANS/PGM + 80

### Dial by name Keys Chart

<b>Q - 11</b>	<b>A - 21</b>	<b>D - 31</b>
<b>Z - 12</b>	<b>B - 22</b>	<b>E - 32</b>
<b>- - 13</b>	<b>C - 23</b>	<b>F - 33</b>
<b>1 - 10</b>	<b>2 - 20</b>	<b>3 - 30</b>
<b>G - 41</b>	<b>J - 51</b>	<b>M - 61</b>
<b>H - 42</b>	<b>K - 52</b>	<b>N - 62</b>
<b>I - 43</b>	<b>L - 53</b>	<b>O - 63</b>
<b>4 - 40</b>	<b>5 - 50</b>	<b>6 - 60</b>
<b>P - 71</b>	<b>T - 81</b>	<b>W - 91</b>
<b>Q - 72</b>	<b>U - 82</b>	<b>X - 92</b>
<b>R - 73</b>	<b>V - 83</b>	<b>Y - 93</b>
<b>S - 74</b>	<b>8 - 80</b>	<b>Z - 94</b>
<b>7 - 70</b>		<b>9 - 90</b>
<b>*1 - Blank</b>	<b>0-00</b>	<b>#</b>
<b>*2 - :</b>		
<b>*3 - ,</b>		




The **MENU** key is used edit phone settings




The **MSG** key is used to check voice mail messages




The **TRANS/PGM** key is used to **TRANSFER** calls and **PROGRAM** system features on the keyset




The **HOLD/SAVE** key is used to place calls on **HOLD**, it is also used to confirm the programming of features




The **MUTE** key mutes the microphone so the other party cannot hear you



The **SPEAKER** key is used to activate the speaker on the phone for the hands free speaker-phone




The **DND** key puts your phone in Do not disturb mode so you will not receive any calls, also switches phone into Day/Night/Auto modes



The **Headset** key lets you choose between Speaker / Headset modes



The **Vol ▲** key increase the volume of Ring tone, hand piece and speaker



The **Vol ▼** key decrease the volume of Ring tone, hand piece and speaker



**For Service Call:**  
**06 3570900**  
**Fax**  
**063570901**  
**Email**  
**info@telephonics.co.nz**  
**Web**  
**www.telephonics.co.nz**

- **Flexible keys:** The colour of the LED signifies the status of stations, or lines.
- Feature access also can be programmed on these keys.
- 



**User Guide**  
**12/24 Button Keyphone**